

AAVA

SIPARILA WOOD FOR LIVING

Maintenance Guide



MAINTENANCE INSTRUCTIONS

- Dirty surfaces can be cleaned with a wet cloth and regular household detergent diluted with water according to the detergent instructions.
- Abrasive cleaning agents are not recommended.
- Persistent stains that do not respond to water cleaning can be removed with mild solvents like white spirit or mild alcohol-based cleaning agents. Wet the cloth with the solvent and wipe gently.
- Please note that solid solvents like acetone and turpentine should be avoided, as these substances may soften the original surface treatment.

MAINTENANCE PAINTING

- Begin by thoroughly cleaning the surface that requires treatment.
- Prior to applying the maintenance paint, please verify that the color is appropriate by testing it on a discreet section of the surface. Apply a thin layer of the surface treatment agent. To achieve a darker shade, consider applying additional layers as needed.
- It is essential to carefully read and adhere to the product instructions before proceeding with maintenance painting.

RECOMMENDED PRODUCTS

- SNOWFALL
 - Tikkurila Helmi multipurpose furniture paint 10
- BEACH
 - Dry areas: Tikkurila Paneeli-Ässä, tone TVT3440, Water-borne, tintable acrylic lacquer for interior use.
- POLAT NIGHT
 - Dry areas: Tikkurila Paneeli-Ässä, tone TVT3445, Water-borne, tintable acrylic lacquer for interior use.